


FIGURE 1



2.00

FIGURE 2

SEND ATM-TDM correlation tag AND ATM SOURCE ID
FROM ATM SOURCE GATEWAY TO TELEPHONY
SIGNALING CONTROL NETWORK 301

SEND ATM-TDM correlation tag AND ATM SOURCE ID
FROM TELEPHONY SIGNALING CONTROL NETWORK
TO ATM DESTINATION GATEWAY 302

SEND SETUP MESSAGE WITH ATM-TDM correlation tag FROM
ATM DESTINATION GATEWAY TO ATM SOURCE
GATEWAY 303

FIGURE 3